
## A NOTE ABOUT OUR SG-LOOM KNOBS:


The wood knobs we provide with our SG-model looms are equiped with a metal insert that is threaded to engage the threads on the metal rods that run through the center of our SG-model loom beams. It is important that the knobs be used in the correct orientation, or the metal insert (called a T-nut) may be pulled out of the knob.

To use the knobs correctly, hold them so the side of the knob with the larger hole is in your palm. The threaded rod is screwed into the smaller hole on the other side of the knob. The smaller hole will be against the washer on the loom's side, while the larger hole remains visible on the outside of the knob, when the knob is tightened

The larger hole is oriented away from the loom, and remains visible.



The smaller hole goes against the loom during use.




NOTE: Do not over-tighten the knobs. In normal use, you should stop tightening the knobs when they are firmly screwed against the washer on the loom's side. Over-tightening can result in the threads of the metal insert being stripped.



## IMAGINATION STARTS HERE

The Heddle Blocks are independent accessories to the loom. They are used to hold a heddle upright, while sitting on a table top; and then only to hold the heddle while it is being threaded with warp yarn. Once the loom is warped, the heddle blocks should be set aside (the heddle will be held in place by the tension of the



warp yarn). You can use additional heddle blocks if threading additional heddles. They are not used in the weaving process. The shed blocks (square blocks pre-attached to the sides of the loom) are big enough to hold 3 heddles (the heddles will be held in place by the tension of the warp yarn)!

Our goal is to make quality wood items that encourage imaginations and enhance creativity! To learn more about Beka, visit our website: www.Bekainc.com

Thanks, ~The Beka Folks

