

Trundle Assembly Instructions

Contents:

- 4 maple end pieces (2 with a slot)
- 2 baltic birch sides
- 1 bottom piece
- 16 wood screws
- 4 swivel casters

A phillips screwdriver is needed for assembly.

Step 1:

With the bottom's white side facing up, slide the slotted maple end pieces and one of the baltic birch side pieces into position as shown. Secure with 4 screws.

Step 2:

Place the remaining baltic birch side with it's slot down and in, to capture the bottom piece. Secure with 4 screws.

Step 3:

Position remaining maple end pieces so the holes in their ends line up with the remaining holes in the sides. Turning the partially assembled box on it's side may make it easier to secure the pieces with the remaining screws.

Step 4:

Turn the assembled trundle (box) upside down, so the holes in the edge of the two slotted maple end pieces are "up".

Press the 4 swivel casters into place in the holes provided. Be careful to insert them fully (do not pinch your fingers in this process!).

Caution: This product is not designed as a ride-on toy. It is intended for use as a moveable storage container. Please supervise children accordingly.

Warning – Adult Assembly Required!

Enclosed hardware includes sharp points and small parts packed in plastic bags, so may present hazards to children prior to assembly. Dispose of plastic bags, extra hardware and any packing material to avoid potential choking hazards. After assembly, an adult should check hardware regularly to insure it is tight.











assembled Trundle right side up

Thank you for choosing Beka!

Your new Beka product is designed for fun and function, and made by Minnesota Makers in our St. Paul shop, where we've produced specialty products since 1973.

Our goal is simple: Make quality wood products that encourage imaginations and enhance creativity; then provide fast, friendly, and reliable service.

We're working hard to do just that!

We're always adding new items for you to enjoy, so please ask your favorite specialty retailer about other Beka products.

> Or learn more about Beka by visiting our web site www.Bekainc.com

or call us for referral to your nearest retailer: 1-888-999-(BEKA)2352